



# Mossberg Side Saddle

Part # A.5.10.1630

Advanced Technology  
INTERNATIONAL

## -Installation Instructions-

**Point the shotgun in a safe direction and place the safety in the "on" position. Next pull back the slide, and carefully inspect the chamber to be sure the shotgun is unloaded.**



### Mossberg Side Saddle Installation

#### Step #1

Begin by removing the (4) 8-40 x 3/16" existing set screws from the top of the receiver using a small flat head screwdriver.



Figure 1

#### Step #2

Next, mount the ATI Halo Side Saddle to the receiver using the (4) 8-40 x 3/8" flat head screws provided and a 3/32" allen wrench.



Figure 2A

Figure 2B

Advanced Technology International • Made In the USA • Limited Lifetime Warranty  
2733 West Carmen Ave • Milwaukee, WI 53209  
Toll Free: 800.925.2522 • Fax: 414.464.3112

[www.ATIGunstocks.com](http://www.ATIGunstocks.com)