

Hi-Lux, Inc.

3135 Kashiwa Street, Torrance, CA 90505, Tel: (310) 257-8142, Fax: (310) 257-8096

OFF-SET PLATE WITH ½" 60° BASE MOUNT (OSPWB) INSTALLTION INSTRUCTION





One problem the muzzleloading shooter and hunter runs into when trying to install a riflescope on a muzzleloader of very traditional "side-hammer" design is getting the scope off-set enough to insure that the hammer can still be drawn back to full cock - and that it does not hit the scope tube when the trigger is pulled. No one mount arrangement works well with all rifles. However, for the vast majority of those who shoot and hunt with a rifle of traditional styling, their rifle of choice is

three-fourths of the time a percussion ignition rifle

with an octagonal barrel.

For those rifle owners, Hi-Lux Optics now offers a simple set of off-set bases that gives the scope plenty of hammer clearance, yet does not have the scope setting so far off to the side that the shooter has to pull his or her head off of the butt stock to properly align their eye with the rear lens.

Depending on the caliber, load and especially the amount of recoil produced, these bases can be attached to the top flat of an octagon barrel using either two or three screws. Three holes for attaching are pre-drilled on the plate.



The blocks are attached and one of the 1880s style Malcolm scopes can be easily slipped right on and

tightened in place. (These come in 17" long 3x and 18" long 6x models.) Location of the bases on the barrel is determined by where the scope will need to set in order to provide the proper eye relief, which can be adjusted several inches forward or rearward by loosening the ring of the front Malcolm mount and sliding the scope in the direction it needs to go. Also, the simple design of the Hi-Lux off-set bases allow them to be simply turned around and mounted with the blocks off-set in the other direction on left-handed rifles. The rifle in the accompanying photograph is a custom half-stock built by Toby Bridges back in the early 1980s.

If you have any questions about this product, please feel free to contact us at the toll free no. 1-888-HI-LUX-12 (445-8912) or send us an e-mail to techsupport@hi-luxoptics.com.

WARNING:

You must install the mount securely before you shoot the rifle. This should be done by a competent gunsmith.

TOP VIEW